



Do These Five Things Before Taking Cover — Long Before



Install a hurricane resistant assembly from Curries — tested to withstand violent wind storms in hurricane-prone areas



Get a door that meets the design pressure of +/- 50 psf to +/- 150 psf



Make it water infiltration tight: +/-50 psf to +/-60 psf



Confirm third-party testing by UL and ITS/WH certified



Explore your hardware options including brands such as CORBIN RUSSWIN, RIXSON, SARGENT, YALE, and frame options from single and paired openings to sidelights and transom options